This model was tested in Cura 3.5.1 and printed on an Ultimaker 2 in PLA material.

Recommendations: For all parts of Locks you need to change "Brim" type to "Skirt" in Build Plate Adhesion section.

To avoid printing problems, we recommend the following settings:

Quality

Layer Height: 0.1 mm Initial Layer Height: 0.3 mm

Line Width: 0.4 mm
Wall Line Width: 0.4 mm

Outer Wall Line Width: 0.4 mm Inner Wall(s) Line Width: 0.4 mm Top/Bottom Line Width: 0.4 mm

Infill Line Width: 0.4 mm

Skirt/Brim Line Width: 0.4 mm Support Line Width: 0.4 mm Initial Layer Line Width: 100%

Shell

Wall Thickness: 0.8 mm Wall Line Count: 2

Outer Wall Wipe Distance: 0.2 mm

Top Surface Skin Layers: 0 Top/Bottom Thickness: 0.8 mm

Top Thickness: 0.8 mm

Top Layers: 8

Bottom Thickness: 0.8 mm

Bottom Layers: 8
Top/Bottom Pattern: Lines

Bottom Pattern Initial Layer: Lines Top/Bottom Line Directions: []

Outer Wall Inset: 0 mm

Compensate Wall Overlaps: Check

Compensate Outer Wall Overlaps: Check Compensate Inner Wall Overlaps: Check

Fill Gaps Between Walls: Everywhere

Filter Out Tiny Gaps: Check Horizontal Expansion: 0 mm

Initial Layer Horizontal Expansion: 0 mm Z Seam Alignment: Sharpest Corner Seam Corner Preference: Hide Seam Ignore Small Z Gaps: Check Extra Skin Wall Count: 1

Infill

Infill Density: 20%

Infill Line Distance: 4.0 mm

Infill Pattern: Grid
Infill Line Directions: []
Infill X Offset: 0 mm
Infill Y Offset: 0 mm

Infill Overlap Percentage: 10%
Infill Overlap: 0.04 mm
Skin Overlap Percentage: 5%
Skin Overlap: 0.02 mm
Infill Wipe Distance: 0.1 mm
Infill Layer Thickness: 0.1 mm

Gradual Infill Steps: 1

Gradual Infill Steps Height: 1.5 mm

Infill Before Walls: Check Minimum Infill Area: 0 mm2 Skin Removal Width: 0.8 mm

Top Skin Removal Width: 0.8 mm Bottom Skin Removal Width: 0.8 mm

Skin Expand Distance: 0.8

Top Skin Expand Distance: 0.8
Bottom Skin Expand Distance: 0.8
Maximum Skin Angle for Expansion: 90°
Minimum Skin Width for Expansion: 0.0

Material

Initial Layer Flow: 100% Enable Retraction: Check

Retraction Extra Prime Amount: 0 mm3
Retraction Minimum Travel: 0.8 mm
Maximum Retraction Count: 90

Minimum Extrusion Distance Window: 6.5 mm Nozzle Switch Retraction Distance: 16 mm Nozzle Switch Retraction Speed: 20 mm/s Nozzle Switch Retract Speed: 20 mm/s Nozzle Switch Prime Speed: 20 mm/s

Speed

Print Speed: 45 mm/s

Infill Speed: 45 mm/s Wall Speed: 22.5 mm/s

Outer Wall Speed: 22.5 mm/s Inner Wall Speed: 45 mm/s Top/Bottom Speed: 15 mm/s Support Speed: 45 mm/s Support Infill Speed: 45 mm/s

Travel Speed: 45 mm/s

Initial Layer Speed: 22.5 mm/s

Initial Layer Print Speed: 22.5 mm/s Initial Layer Travel Speed: 30 mm/s

Skirt/Brim Speed: 45 mm/s Maximum Z Speed: 0 mm/s Number of Slower Layers: 2

Travel

Combing Mode: All

Avoid Printed Parts when Traveling: Check

Travel Avoid Distance: 0.6562 mm

Layer Start X: 0.0 mm Layer Start Y: 0.0 mm

Cooling

Enable Print Cooling: Check

Fan Speed: 100%

Regular Fan Speed: 100% Maximum Fan Speed: 100%

Regular/Maximum Fan Speed Threshold: 10 s

Initial Fan Speed: 0%

Regular Fan Speed at Height: 0.3 mm

Regular Fan Speed at Layer: 2

Minimum Layer Time: 5 s Minimum Speed: 10 mm/s

Support

Generate Support: Check

Support Placement: Everywhere Support Overhang Angle: 60° Support Pattern: Zig Zag

Connect Support ZigZags: Check

Support Density: 15 %

Support Line Distance: 2.2 mm Support Z Distance: 0.13 mm Support Top Distance: 0.13 mm Support Bottom Distance: 0.13 mm

Support X/Y Distance: 1 mm

Support Distance Priority: Z overrides X/Y Minimum Support X/Y Distance: 0.25 mm

Support Stair Step Height: 0.3 mm

Support Stair Step Maximum Width: 5.0 mm

Support Join Distance: 2.0 mm

Support Horizontal Expansion: 0.2 mm Support Infill Layer Thickness: 0.1 mm

Gradual Support Infill Steps: 0

Use Towers: Check Tower Diameter: 3.0 mm Minimum Diameter: 3.0 mm Tower Roof Angle: 65°

Build Plate Adhesion

Build Plate Adhesion Type: Brim (for all parts of locks use "Skirt")

Skirt/Brim Minimum Length: 250 mm

Brim Width: 8.0 mm
Brim Line Count: 15

Brim Only on Outside: Check

Mesh Fixes

Union Overlapping Volumes: Check Merged Meshes Overlap: 0.15 mm

Special Modes

Print Sequence: All at Once Surface Mode: Normal

Experimental

Slicing Tolerance: Middle

Maximum Resolution: 0.01 mm

Flow rate compensation max extrusion offset: 0 mm

Flow rate compensation factor: 100%

Disclaimer: This model will look outstanding if printed on SLA/SLS 3D printer. The accuracy of the model printed on FFF printer can vary from the result shown in the pictures.